



Haptic 6 Click schematic v100



*NOTE: MCLR only enabled after
ACK Reset has been set.*



www.mikroe.com