


PIC18, PIC18FJ, PIC24FJ
USB HID BOOTLOADER FLASH MEMORY LAYOUT



* Application code must have some configuration word settings as bootloader firmware.